

C10 - C11

- Pushback facing south-west on Taxilane W7 and pull ahead till abeam stand No. C11
- Taxi out via Taxilane W7.

**CAUTION :**

Aircraft on Stands C10 to C11 not to commence pushback until the aircraft pushing back from Stand C12 has taxied out.

