

VABB/BOM

AIRCRAFT PUSHBACK PROCEDURE

MUMBAI INDIA
CHHATRAPATI SHIVAJI
MAHARAJ INTL APT.

Runway 32

Stands - C12 - C20

C12-C19

- Pushback facing south-west on Taxilane W7
- Taxi out via Taxilane W7.

C20

- Pushback deep on Taxilane W7 facing south till abeam stand C18 clear of Twy N.
- Taxi out via Taxilane W7.

CAUTION :

Aircraft on Stand C12 not to commence pushback until the aircraft pushing back from Stand C10&C11 has taxied out.
Stands C18, C19 & C20 are interdependent

